Philips
CD Soundmachine with
Dynamic Bass Boost

AZ1027

Enjoy music wherever you go

You take pleasure in the simple things in life and delight in convenience. The sleek and portable AZ1027 lets you indulge in the pleasures of enjoying your favorite music with the help of easy-to-use functions.

The ultimate listening experience
- Plays CD, CD-R and CD-RW discs
- Autostop stereo cassette deck
- FM/MW stereo tuner

Easy to use
- 20-track CD programmable
- CD shuffle/program/repeat
- MP3 link for portable music playback

Rich and clear sound experience
- Dynamic Bass Boost for deep and dramatic sound

PHILIPS
sense and simplicity

CD Soundmachine with Dynamic Bass Boost

AZ1027/12

Specifications

Audio Playback
- Loader Type: Top
- Playback Media: CD, CD-R, CD-RW
- Disc Playback Modes: Fast Forward/Backward, Next/Previous Track Search, Repeat Play, Shuffle Play
- Number of decks: 1
- Cassette Deck Technology: Mechanical
- Programmable Tracks: 20

Tuner/Reception/Transmission
- Tuner Bands: FM, MW
- Antenna: FM Antenna

Sound
- Output power (RMS): 2 X 1W
- Sound Enhancement: Dynamic Bass Boost
- Sound System: Stereo
- Speaker diameter: 3.5"
- Volume Control: rotary

Audio Recording
- Tape Recording Enhancement: CD Synchro Start Recording
- Recording Media: Tape

Convenience
- Display Type: LCD

Connectivity
- 3.5mm stereo line in: (MP3 LINK)

Power
- Battery type: LR14
- Battery voltage: 1.5 V
- Mains power: 220V - 230V
- Number of batteries: 6

Accessories
- Included Accessories: AC Power Cord, User Manual, Warranty certificate

Dimensions
- Packaging dimensions (W x H x D): 320 x 275 x 175 mm
- Product dimensions (W x H x D): 291 x 146 x 243 mm
- Weight: 1.8 kg
- Weight incl. Packaging: 2.4 kg

Product highlights

Autostop stereo cassette deck

CD shuffle/program/repeat

MP3 link for portable music
MP3 link allows direct playback of MP3 files from your portable media player on your audio system. Simply connect your portable media player to the built-in MP3 link jack on an audio system and enjoy your MP3 music in superior sound quality.

Dynamic Bass Boost
Dynamic Bass Boost maximizes your music enjoyment by emphasizing the bass content of the music throughout the range of volume settings - from low to high – at the touch of a button! Bottom-end bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be switched on to boost bass levels, so you can enjoy consistent sound even when you turn down the volume.

Issue date 2008-10-15

Version: 1.0.8

12 NC: 8670 000 40399
EAN: 87 12581 42897 6

© 2008 Koninklijke Philips Electronics N.V.
All Rights reserved.

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.

www.philips.com